

P122 – TOCCO METALLICO

Description

Decorative finish with a soft metallic appearance and velvety to the touch, which gives the surface a highly prestigious smooth spatula effect, with peculiar reflections of silvery light.

Application

Preparation of the base.

On gypsum-based walls or fine civil plaster, clean the surface until obtaining a homogeneous, dry and dust-free surface. For plasterboard, laminate, tiles, iron, wood, etc. use a specific adhesion promoter before applying the specific basecoats.

Apply a coat of **H3.300 FONDO L**, diluted 20% by volume with water, using the specific Roller L or a flat brush. If necessary, apply a second coat of **H3.300 FONDO L** depending on the degree of absorption and coverage of the substrate.

Coloring of the finish.

Color **TOCCO METALLICO** with the **HYCOL** of the color code chosen on the color chart according to the table below. After coloring, mix thoroughly.

<i>Product base packaging</i>	<i>Toner dose</i>
750ml	20 ml
3 litres	80 ml

Application of the Finish.

When the basecoat is well dried (minimum 3 hours), apply a first generous undiluted coat of TOCCO METALLICO in the same color to the wall using the appropriate Roller or flat brush. After applying approximately 2 m². of product, use the Spatula R plastic accessory to smooth the surface and create the desired spatula design.

<i>Coats</i>	<i>Operation</i>	<i>Dilution (Water - Vol %)</i>	<i>Tools (picto)</i>	<i>Approx coverage (m²/liter per coat)</i>
	Adequate preparation of the substrate			
1 (2)	Application Fund L	20%	Roller L Flat brush	10
1	Application colored Tocco metallico	Undiluted	Roller NA Spatula R	6.5

Rev.0 dated 01/17/2024